



Removal

- 1 Apply screw driver to force holding spring of dome lamp (at right of recess) in inward direction and pull dome lamp out of paneling.




- 2 Unscrew fastening screws on paneling.
- 3 Lower paneling at rear end and carefully pull out of roof frame and the two glass panes in luggage compartment in rearward direction.



Installation

- 4 Attach paneling with the two holders of frame.
- 5 Screw down paneling.
- 6 Attach dome lamp by means of clips.



168-15678

7 Force end of paneling on roof frame under rubber frame of glass pane by means of a plastic wedge or the like.

